

POST LINK Setup Of TMS Parameters

Parameters are set via the [LOAD POST] key.

The following TMS ® parameters can be set:

- Transmission Speed
- Select Mode
- Phone Standard
- Telephone Number

To change any of the TMS ® parameters, press the [LOAD POST] key until the display shows:

Change TMS
Parameters [E]

After entering the Change TMS Parameters menu, you can scroll through the parameters without making changes by pressing the [LOAD POST] key.

Transmission Speed

Then press the [ENTER] key, the subsequent display will show:

Selections:

- 1200 bps
- 2400 bps

Transmission
2400 BPS [E]

Press the [ENTER] key to change
The Transmission speed between the
Selections of 2400 and 1200 baud
per second. Press [LOAD POST] to
enter your selection and to advance
to the next parameter.

The Transmission
Speed is normally
set at 2400 BPS

Mode Selection

Selections:

- Wait Dial Tone
- Wait 5 seconds

Select Mode:
Wait Tone [E]

Press the [ENTER] key to scroll between
The Wait Tone and Wait 5 seconds
selections. After you have made your
Selection, press the [LOAD POST] key to
Enter your selection and advance to the
next parameter. (At any point, you can
Press the [EXIT] key to return to the main menu selection.)

**The Mode
Selection is
normally set
at Wait Tone**

Phone Standard

Selections:

Tone
Pulse

Phone Standard:
[E]

Press the [ENTER] key to scroll between The Phone Standard selections of Tone and Pulse: when you have made your selection, press the [LOAD POST] key to advance to the next parameter.

Pulse is used
for a rotary
dial phone

Telephone Number TMS Center

Telephone Number
TMS Center
[E]

Press the [ENTER] key and the display will show:

Tel No.....
.....1-800-237-0696

The display shows the default TMS® number. If need use the numeric keys To change the TMS® Center telephone Number (for example: a “9” for an outside line). If needed, use the [.] to enter one-Second pauses. Then press [ENTER].

Example: [9] [.] [1] [8] [0] [0] [.] [2] [3] [7] [.] [0] [6] [9] [6]

[ENTER]

Tel No. 9.1.800.237.0696

If your phone system requires nine to dial an outside line, the entering of the TMS® Center’s telephone number should reflect this: 9. 1. 800. 2370696

When finished, press the [EXIT] key and the display will return to the Change TMS Parameters screen.

**Change TMS
Parameters**
[E]

Setting of TMS® parameters is complete. Press [EXIT].